



LG Voyager Camera Replacement

This guide will show you how to remove a defective camera from an LG Voyager and replace it with a new one.

Written By: KateOshea



INTRODUCTION

If your LG Voyager camera is not working properly, you can replace it by following the steps in this guide.



TOOLS:

- [Spudger](#) (1)
 - [iFixit Opening Tools](#) (1)
 - [Phillips #00 Screwdriver](#) (1)
-

Step 1 — Camera




- Remove the battery by pressing the button below it and lifting it out.

Step 2




- Unscrew all four screws from the corners of the back cover.
- Using a plastic opening tool, gently remove the back cover.

Step 3



- Slightly lift the small silver panel located to the right of the camera.

Step 4



- Remove the tan plastic camera cover.

Step 5




- Lift the connector with a spudger.

Step 6



- Remove the camera by carefully separating it from the tape underneath it.



© iFixit — CC BY-NC-SA